

Truax Hotel Ground Floor/Basement Level

3RD STREET




BASEMENT FLOOR WEST TOWER ONLY


Truax Hotel First Floor




Truax Hotel Second Floor




Truax Hotel Third Floor



Truax Hotel Fourth Floor



Truax Hotel Fifth Floor



Truax Hotel Sixth Floor

